


RB398 *Rebar Tying Tool*



RB398 PARTS LISTING

It#	Part #	Description	It#	Part #	Description	It#	Part #	Description
1	BB40112	BOLT 3X6	68	FF31563	PIN 1563	137	KK23561	COMPRESSION SPRING 3561
2	BB86701	TORX BOLT 3X5	69	KK34089	SPRING 4089	138	BB40710	BOLT 3X8
3	RB70404	ARM B UNIT(397)	70	RB81181	RATCHET COVER ASSY	140	BB40709	BOLT 3X16
4	RB11999	WIRE GUIDE B(397)	71	BB40425	BOLT 3X10	141	RB12236	PLATE A
5	RB12000	CUTTER	72	RB10421	LABEL, FCC (USA)	142	CC42512	HEX NUT 1A M4
6	JJ10109	E-RING 2	73	RB70476	MOTOR COVER ASSY (RB397USA)	143	RB12098	WARNING LABEL
7	RB12090	CUTTER LEVER B(397)	74	FF41821	STEP PIN 1821	145	FF52111	PIN 2111
8	JJ10514	E-RING 3 CF	75	KK34067	TORSION SPRING 4067	146	BB41503	BOLT 3X8
9	RB12005	CUTTER LEVER A(397)	76	EE39609	RUBBER WASHER 1.8X6X2	147	RB11979	COVER L (RB397)
10	FF51686	PIN 1686	77	BB40714	BOLT 3X50	148	RB81253	FRAME L ASSY
11	RB11846	SHAFT	78	RB12031	JOINT	149	RB11987	WINDOW
12	RB12004	CONNECTING ROD(397)	79	RB11846	SHAFT	150	RB81195	RELAY BOARD UNIT
13	RB10392	PIN	80	RB81178	REEL HOLDER ASSY	151	RB81191	SENSOR CIRCUIT D BOARD UNIT
14	RB11998	WIRE GUIDE A(397)	81	RB81179	REEL MAGAZINE	152	AA31724	SCREW 2X8
15	RB12121	FIXED CUTTER (N)	82	RB12038	REEL STOPPER SPRING	153	RB12080	TRIGGER (RB397)
16	RB12228	CUTTER LEVER A	83	EE39907	WASHER 3.1X12X0.8	154	KK23656	COMPRESSION SPRING 3656
17	RB12265	CONNECTING ROD	84	RB12035	REEL STOPPER	155	RB12101	TRIGGER LOCK LEVER (RB397)
18	RB10392	PIN	85	FF21240	PIN 2.5X6	156	RB70453	TRIGGER AWITCH UNIT (RB397)
19	AA71408	SCREW 3 X 3	86	RB12036	STOPPER PLATE	157	RB70473	SWITCH LEVER UNIT
20	FF51667	PIN 1667	87	RB70427	REEL STOPPER	158	KK34083	SPRING 4083
21	RB11814	WIRE GUIDE SCREW	88	RB81180	REEL MAGAZINE ASSY	159	RB11686	SWITCH LEVER PIN
22	KK33370	SPRING 3370	89	RB12099	PLATE B	160	RB81225	MAIN CIRCUIT BOARD UNIT (RB517)
23	RB12003	SCREW	90	BB41707	BOLT 4X16	161	RB70465	REPLAY BOARD HARNESS UNIT(RB397)
24	RB12007	PIPE SPONGE	91	EE11103	SPRING WASHER 2-4	162	RB70454	INTERFACE HARNESS UNIT (RB397)
25	FF51686	PIN 1686	92	EE39825	WASHER 4.5X7.4X0.8	163	RB81188	ELECTRODE UNIT
26	JJ10101	E-RING 4	93	KK24175	COMP. SPRING 4175	164	RB70464	BATTERY SIGNAL HARNESS UNIT
27	RB81219	PIPE ASSY (RB517)	94	JJ10113	E-RING 2.5	165	RB11981	COVER R (RB397)
28	RB81224	URL GUIDE UNIT (RB517)	95	RB10359	FEEDING GEAR B2	166	RB11983	LABEL CURL GUIDE
29	RB12010	CURL GUIDE COVER	96	RB10362	RELEASE LEVER	167	RB11985	USAGE LABEL
30	KK33365	TORSION SPRING	97	FF41809	STEP PIN 1809	168	RB11982	LABEL, MAIN SWITCH
31	RB11708	STOPPER SHAFT	98	FF51628	HOLLOW PIN 1628	169	RB12303	517 LABEL (RB517USA)
32	RB81217	CURL GUIDE ASSY (RB517)	99	EE32104	WASHER 2-3	171	RB81226	FRAME R ASSY (RB517USA)
33	RB11816	HOOK	100	RB10357	FEEDING GEAR B1	172	BB40810	BOLT 3X16
34	RB81113	WS PIN 2.5X10	102	RB10364	WIRE GUIDE C	173	RB81184	BELT HOOK ASSY
35	RB12014	KEY B	103	CC41104	HEX.NUT 1-3 FOR HD-12/17	174	RB12039	LED COVER
36	RB12280	SLEEVE A	104	RB70434	PARTITION PLATE	175	BB41708	BOLT 4X10
37	RB12279	SLEEVE GUIDE	105	RB12045	PARTITION SPONGE	176	AA31722	SCREW 3X8
38	RB81242	TIP AXIS B	106	RB12421	SPONGE SUPPORT			
39	RB10115	KEY B	107	RB70509	FEEDING GEAR A ASSY			
40	KK23730	COMP. SPRING 3730	108	RB81266	FEEDING MOTOR ASSY			
41	RB12281	TIP AXIS A	109	RB81267	FEEDING ASSY			
42	RB12015	SLEEVE B	110	RB10368	JAW A			
43	RB70412	CUTTER RING UNIT	111	KK33249	TORSION SPRING 3249			
44	RB12091	CUTTER RING GUIDE	112	RB10370	JAW BASE			
45	JJ21011	C-RING 14	113	FF41822	STEP PIN 1822			
46	RB81247	TIP AXIS ASSY	114	RB10369	JAW B			
47	RB12020	SPRING COLLAR	115	RB70495	JAW BASE ASSY			
48	KK29026	COMP. SPRING 9026	116	RB12238	ROTARY PIN			
49	RB12019	BUMPER	117	RB81185	SOLENOID ASSY			
50	RB81177	TIP AXIS GUIDE ASSY	118	FF41855	PIN 1855			
51	JJ21603	C-RING 20	119	JJ10106	E-RING 6			
52	RB10338	INTERNAL GEAR	120	RB12030	PALTE C			
53	LL11181	WHEEL 6704	121	RB12029	ROTARY PLATE			
54	RB70408	PLANETCAGE UNIT	122	FF21620	PIN 2X12			
55	FF31589	PIN 1589	123	RB70531	BRAKE ASSY			
56	RB10341	PLANET GEAR	124	BB40712	BOLT 4X8			
57	RB10484	GEAR PRESS WHEEL	125	RB12025	REEL PRESS			
58	RB70418	SUN GEAR UNIT	126	KK33373	SPRING 3373			
59	RB70558	TWISTING MOTOR (RB517)	127	FF52114	HOLLOW PIN 2114			
60	AA21419	SCREW 3X8	128	RB70457	MAIN SWITCH UNIT (RB397)			
61	FF51817	HOLLOW PIN 1817	129	RB12267	LABEL, TORQUE DIAL (RB517)			
62	RB81248	WIRE GUIDE A ASSY	131	RB81232	SWITCH BASE ASSY (RB517)			
63	RB81246	REEL GUIDE ASSY	132	RB12054	STEP PIN			
64	RB12284	REEL GUIDE	133	RB12053	RELEASE STOPPER			
65	AA05555	SCREW 3X6 CF	134	RB12055	STOPPER BASE			
66	RB11687	NUT PLATE	135	RB12056	SPONGE F			
67	BB41706	BOLT 4X10	136	RB81139	STOPPER BASE ASSY			

AIRMATIC

airmatic.com | 215.333.5600 | infocenter@airmatic.com